

CBIOS4.PRN

```

*****
*
* CBIOS FOR CP/M VER 2.2 FOR DISK JOCKEY 2D CONTROLLER (ALL
* REVS). HANDLES DISKETTES WITH SECTOR SIZES OF 128 BYTES
* SINGLE DENSITY, 256, 512, 1024 BYTES DOUBLE DENSITY.
*
* WRITTEN BY BOBBY DALE GIFFORD.
* 9/1/79
*
* CUSTOMIZED BY JAY O'BRIEN.
* 4/12/81
*
* MODIFIED FOR ADDITIONAL PRINTER ON PORT 0 WITH PRINTER BUSY
* ON PORT 5 BIT 1
* 11/9/81
*
* DISK MAP OF SECTORS USED BY COLD BOOT, WARM BOOT, FIRMWARE,
* AND CP/M:
*
* TRK 0 SEC 1 = FIRST SECTOR OF COLD BOOT.          E700H
*           2 = COLD BOOT 256.                      80H
*           3 = COLD BOOT 512.                      80H
*           4 = COLD BOOT 1024.                     80H
*           5 = WARM BOOT 256.                      80H
*           6 = WARM BOOT 512.                      80H
*           7 = WARM BOOT 1024.                     80H
*           8 = COLD/WARM BOOT.                     3200H
*           9 = FIRMWARE.                           E400H
*          10 = FIRMWARE+80H.                        E480H
*          11 = FIRMWARE+100H                       E500H
*          12 = FIRMWARE+180H.                      E580H
*          13 = FIRMWARE+200H.                      E600H
*          14 = FIRMWARE+280H.                      E680H
*          15 = FIRMWARE+300H.                      E700H
*          16 = FIRMWARE+380H.                      E780H
*          17 = CCP.                                2D00H
*          18 = CCP+80H.                            2D80H
*          19 = CCP+100H.                           2E00H
*          20 = CCP+180H.                           2E80H
*          21 = CCP+200H.                           2F00H
*          22 = CCP+280H.                           2F80H
*          23 = CCP+300H.                           3000H
*          24 = CCP+380H.                           3080H
*          25 = CCP+400H.                           3100H
*          26 = CCP+480H.                           3180H
*          1  = REST OF CP/M.                      3200H-4FFFH
*
*****

```

TITLE '\*\*\* Cbios For CP/M Ver. 2.2 \*\*\*'

```

*****
*
* THE FOLLOWING REVISION NUMBER IS IN REFERENCE TO THE CP/M
* 2.0 CBIOS.
*

```

The BIOS IN THE  
MOV (PRN) IFM  
WORKS FINE.

```

*****
001E = REVNUM EQU 30 ;CBIOS REVISION NUMBER
0016 = CPMREV EQU 22 ;CP/M REVISION NUMBER
*****

```

```

*****
*
* THE FOLLOWING EQUATES RELATE THE THINKER TOYS 2D CONTROLLER.
* IF THE CONTROLLER IS NON STANDARD (0E000H) ONLY THE ORIGIN
* EQUATE NEED BE CHANGED. THIS VERSION OF THE CBIOS WILL WORK
* WITH 2D CONTROLLER BOARDS REV 0, 1, 3, 3.1, 4.
*
*****

```

```

E000 = ORIGIN EQU 0E000H
E400 = DJRAM EQU ORIGIN+400H ;DISK JOCKEY 2D RAM ADDRESS
E403 = DJCIN EQU DJRAM+3H ;DISK JOCKEY 2D CHARACTER INPUT ROUTINE
E406 = DJCOUT EQU DJRAM+6H ;DISK JOCKEY 2D CHARACTER OUTPUT ROUTINE
E409 = DJHOME EQU DJRAM+9H ;DISK JOCKEY 2D TRACK ZERO SEEK
E40C = DJTRK EQU DJRAM+0CH ;DISK JOCKEY 2D TRACK SEEK ROUTINE
E40F = DJSEC EQU DJRAM+0FH ;DISK JOCKEY 2D SET SECTOR ROUTINE
E412 = DJDMA EQU DJRAM+012H ;DISK JOCKEY 2D SET DMA ADDRESS
E415 = DJREAD EQU DJRAM+15H ;DISK JOCKEY 2D READ ROUTINE
E418 = DJWRITE EQU DJRAM+18H ;DISK JOCKEY 2D WRITE ROUTINE
E41B = DJSEL EQU DJRAM+1BH ;DISK JOCKEY 2D SELECT DRIVE ROUTINE
E421 = DJTSTAT EQU DJRAM+21H ;DISK JOCKEY 2D TERMINAL STATUS ROUTINE
E427 = DJSTAT EQU DJRAM+27H ;DISK JOCKEY 2D STATUS ROUTINE
E42A = DJERR EQU DJRAM+2AH ;DISK JOCKEY 2D ERROR, FLASH LED
E42D = DJDEN EQU DJRAM+2DH ;DISK JOCKEY 2D SET DENSITY ROUTINE
E430 = DJSIDE EQU DJRAM+30H ;DISK JOCKEY 2D SET SIDE ROUTINE

```

```

*****
*
* EQUATES FOR MY SYSTEM. J.J. O'BRIEN
*
*****

```

```

E800 = MSDV EQU 0E800H ;VIDEO DRIVER FOR MSDV

```

```

*****
*
* CP/M SYSTEM EQUATES. IF RECONFIGURATION OF THE CP/M SYSTEM
* IS BEING DONE, THE CHANGES CAN BE MADE TO THE FOLLOWING
* EQUATES.
*
*****

```

```

0033 = MSIZE EQU 56 ;MEMORY SIZE OF TARGET CP/M
9000 = BIAS EQU (MSIZE-20)*1024 ;MEMORY OFFSET FROM 20K SYSTEM
BD00 = CCP EQU 2D00H+BIAS ;CONSOLE COMMAND PROCESSOR
C500 = BDOS EQU CCP+800H ;BDOS ADDRESS
D300 = BIOS EQU CCP+1600H ;CBIOS ADDRESS
0004 = CDISK EQU 4 ;ADDRESS OF LAST LOGGED DISK
0080 = BUFF EQU 80H ;DEFAULT BUFFER ADDRESS
0100 = TPA EQU 100H ;TRANSIENT MEMORY
00C0 = INTIOBY EQU 192 ;INITIAL IOBYTE

```

64 = 40  
01000000

192 C 0  
11000000

```

0003 = IOBYTE EQU 3 ;IOBYTE LOCATION
0000 = WBOT EQU 0 ;WARM BOOT JUMP ADDRESS
0005 = ENTRY EQU 5 ;BDOS ENTRY JUMP ADDRESS

```

```

*****
*
* THE FOLLOWING ARE INTERNAL CBIOS EQUATES. MOST ARE MISC.
* CONSTANTS.
*
*****

```

```

000A = RETRIES EQU 10 ;MAX RETRIES ON DISK I/O BEFORE ERROR
000D = ACR EQU 0DH ;A CARRIAGE RETURN
000A = ALF EQU 0AH ;A LINE FEED
0003 = AETX EQU 3 ;A ETX CHAR
0006 = AACK EQU 6 ;A ACK CHAR
0019 = CLEAR EQU 19H ;CLEAR SCREEN FOR MSDV
0004 = MAXDISK EQU 4 ;MAXIMUM # OF DISK DRIVES
0008 = DBLSID EQU 8 ;SIDE BIT FROM CONTROLLER

```

```

*****
*
* THE JUMP TABLE BELOW MUST REMAIN IN THE SAME ORDER, THE
* ROUTINES MAY BE CHANGED, BUT THE FUNCTION EXECUTED MUST BE
* THE SAME.
*
*****

```

```

D300          ORG      BIOS          ;CBIOS STARTING ADDRESS

D300 C3A0D3    JMP      CBOOT        ;COLD BOOT ENTRY POINT
D303 C3FCD3    WBOOTE  JMP      WBOOT    ;WARM BOOT ENTRY POINT
D306 C340D6    JMP      CONST        ;CONSOLE STATUS ROUTINE
D309 C34CD6    JMP      CONIN        ;CONSOLE INPUT
D30C C361D6    COUT   JMP      CONOUT   ;CONSOLE OUTPUT
D30F C381D6    JMP      LIST        ;LIST DEVICE OUTPUT
D312 C376D6    JMP      PUNCH       ;PUNCH DEVICE OUTPUT
D315 C36CD6    JMP      READER      ;READER DEVICE INPUT
D318 C390D4    JMP      HOME        ;HOME DRIVE
D31B C3C6D4    JMP      SETDRV      ;SELECT DISK
D31E C392D4    JMP      SETTRK      ;SET TRACK
D321 C385D4    JMP      SETSEC      ;SET SECTOR
D324 C38AD4    JMP      SETDMA      ;SET DMA ADDRESS
D327 C369D5    JMP      READ        ;READ THE DISK
D32A C362D5    JMP      WRITE       ;WRITE THE DISK
D32D C38CD6    JMP      LISTST      ;LIST DEVICE STATUS
D330 C397D4    JMP      SECTTRAN    ;SECTOR TRANSLATION
D333 C31BE4    DJDRV   JMP      DJSEL   ;HOOK FOR SINGLE.COM PROGRAM

```

```

*****
*
* SIGNON MESSAGE OUTPUT DURING COLD BOOT.
*
*****

```

```

D336 0D0A0A    PROMPT DB      ACR,ALF,ALF

```

11000011  
195 = C3

```

CP/M MACRO ASSEM 2.0      #004      *** Cbios For CP/M Ver. 2.2 ***

D339 35      DB      '0'+MSIZE/10      ;CP/M MEMORY SIZE
D33A 36      DB      '0'+(MSIZE MOD 10)
D33B 4B2043502F      DB      'K CP/M Vers. '      ;CP/M VERSION NUMBER
D348 32      DB      CPMREV/10+'0'
D349 2E      DB      '.'
D34A 32      DB      (CPMREV MOD 10)+'0'
D34B 2C20436269      DB      ', Cbios rev '
D357 332E      DB      REVNUM/10+'0', '.'      ;CBIOS REVISION NUMBER
D359 30      DB      REVNUM MOD 10+'0'
D35A 0D0A      DB      ACR,ALF
D35C 466F722054      DB      'For Thinker Toys Disk Jockey 2D Controller '
D387 402030      DB      '@ 0'

D38A 45      IF      ORIGIN/4096 > 10      ;CONTROLLER ORIGIN (HEX)
                DB      ORIGIN/4096+'A'-10
                ELSE
                DB      ORIGIN/4096+'0'
                ENDIF

                IF      (ORIGIN/256 AND 0FH) > 10
                DB      (ORIGIN/256 AND 0FH)+'A'-10
                ELSE
D38B 30      DB      (ORIGIN/256 AND 0FH)+'0'
                ENDIF
D38C 3030482E      DB      '00H.'
D390 0D0A00      DB      ACR,ALF,0

*****
*
* UTILITY ROUTINE TO OUTPUT THE MESSAGE POINTED AT BY H&L,
* TERMINATED WITH A NULL.
*
*****

D393 7E      MESSAGE MOV      A,M      ;GET A CHARACTER OF THE MESSAGE
D394 23      INX      H      ;BUMP TEXT POINTER
D395 A7      ANA      A      ;TEST FOR END
D396 C8      RZ      ;RETURN IF DONE
D397 E5      PUSH     H      ;SAVE POINTER TO TEXT
D398 4F      MOV      C,A      ;OUTPUT CHARACTER IN C
D399 CD0CD3   CALL     COUT     ;OUTPUT THE CHARACTER
D39C E1      POP      H      ;RESTORE THE POINTER
D39D C393D3   JMP      MESSAGE ;CONTINUE UNTIL NULL REACHED

*****
*
* CBOOT IS THE COLD BOOT LOADER. ALL OF CP/M HAS BEEN LOADED IN
* WHEN CONTROL IS PASSED HERE.
*
*****

D3A0 310001   CBOOT  LXI      SP,TPA      ;SET UP STACK
D3A3 CD3AD7   CALL     TINIT     ;INITIALIZE THE TERMINAL
D3A6 2136D3   LXI      H,PROMPT    ;PREP FOR SENDING SIGNON MESSAGE
D3A9 CD93D3   CALL     MESSAGE    ;SEND THE PROMPT
D3AC AF      XRA      A      ;SELECT DISK A

```

D3AD 32E9D8 STA CPMDRV  
D3B0 320400 STA CDISK

\*\*\*\*\*  
\*  
\* GOCPM IS THE ENTRY POINT FROM COLD BOOTS, AND WARM BOOTS. IT \*  
\* INITIALIZES SOME OF THE LOCATIONS IN PAGE 0, AND SETS UP THE \*  
\* INITIAL DMA ADDRESS (80H). \*  
\*  
\*\*\*\*\*

D3B3 218000	GOCPM	LXI	H,BUFF	;SET UP INITIAL DMA ADDRESS
D3B6 CD8AD4		CALL	SETDMA	
D3B9 3EC3		MVI	A,(JMP)	;INITIALIZE JUMP TO WARM BOOT
D3BB 320000		STA	WBOT	
D3BE 320500		STA	ENTRY	;INITIALIZE JUMP TO BDOS
D3C1 2103D3		LXI	H,WBOOTE	;ADDRESS IN WARM BOOT JUMP
D3C4 220100		SHLD	WBOT+1	
D3C7 2106C5		LXI	H,BDOS+6	;ADDRESS IN BDOS JUMP
D3CA 220600		SHLD	ENTRY+1	
D3CD AF		XRA	A	;A <- 0
D3CE 32EED8		STA	BUFSEC	;DISK JOCKEY BUFFER EMPTY
D3D1 32D5D5		STA	BUFWRTN	;SET BUFFER NOT DIRTY FLAG
D3D4 3A0400		LDA	CDISK	;JUMP TO CP/M WITH CURRENTLY SELECTED DISK IN C
D3D7 4F		MOV	C,A	
D3D8 11FBD3		LXI	D,CMNDBEG	;BEGINNING OF INITIAL COMMAND
D3DB 2108BD		LXI	H,CCP+8	;COMMAND BUFFER
D3DE 3E01		MVI	A,CMNDEND-CMNDBEG+1	;LENGTH OF COMMAND
D3E0 3207BD		STA	CCP+7	
D3E3 47		MOV	B,A	
D3E4 CD37D6		CALL	MOVLOP	
D3E7 3AF9D3		LDA	CWFLG	
D3EA A7		ANA	A	
D3EB 3AFAD3		LDA	AUTOFLG	
D3EE CAF2D3		JZ	CLDBOT	
D3F1 1F		RAR		
D3F2 1F	CLDBOT	RAR		
D3F3 DA00BD		JC	CCP	
D3F6 C303BD		JMP	CCP+3	;ENTER CP/M
D3F9 00	CWFLG	DB	0	;COLD/WARM BOOT FLAG

\*\*\*\*\*  
\*  
\* THE FOLLOWING BYTE DETERMINES IF AN INITIAL COMMAND IS TO BE \*  
\* GIVEN TO CP/M ON WARM OR COLD BOOTS. THE VALUE OF THE BYTE IS \*  
\* USED TO GIVE THE COMMAND TO CP/M: \*  
\*  
\* 0 = NEVER GIVE COMMAND. \*  
\* 1 = GIVE COMMAND ON COLD BOOTS ONLY. \*  
\* 2 = GIVE THE COMMAND ON WARM BOOTS ONLY. \*  
\* 3 = GIVE THE COMMAND ON WARM AND COLD BOOTS. \*  
\*  
\*\*\*\*\*

D3FA 01 AUTOFLG DB 1 ;AUTO COMMAND FEATURE

```

*****
*
* IF THERE IS A COMMAND INSERTED HERE, IT WILL BE GIVEN IF THE
* AUTO FEATURE IS ENABLED.
*   FOR EXAMPLE:
*
*   CMNDBEG DB      'MBASIC MYPROG'
*   CMNDEND DB      0
*
* WILL EXECUTE MICROSOFT BASIC, AND MBASIC WILL EXECUTE THE
* "MYPROG" BASIC PROGRAM.
*
*****

```

```

D3FB 00 CMNDBEG DB      ' '           ;INITIAL COMMAND GOES HERE
CMNDEND DB      0

```

```

*****
*
* WBOOT LOADS IN ALL OF CP/M EXCEPT THE CBIOS, THEN INITIALIZES
* SYSTEM PARAMETERS AS IN COLD BOOT. SEE THE COLD BOOT LOADER
* LISTING FOR EXACTLY WHAT HAPPENS DURING WARM AND COLD BOOTS.
*
*****

```

```

D3FC 310001 WBOOT  LXI      SP,TPA      ;SET UP STACK POINTER
D3FF 3E01    MVI      A,1
D400 =      WFLG  EQU      $-1        ;TEST IF BEGINNING OR
D401 A7      ANA      A              ;   ENDING A WARM BOOT
D402 3E01    MVI      A,1
D404 3200D4  STA      WFLG
D407 32F9D3  STA      CWFLG          ;SET COLD/WARM BOOT FLAG
D40A CAB3D3  JZ       GOCPM
D40D AF      XRA      A
D40E 3200D4  STA      WFLG
D411 4F      MOV      C,A
D412 CD33D3  CALL     DJDRV          ;SELECT DRIVE A
D415 0E00    MVI      C,0           ;SELECT SINGLE DENSITY
D417 CD2DE4  CALL     DJDEN
D41A 0E00    MVI      C,0           ;SELECT SIDE 0
D41C CD30E4  CALL     DJSIDE
D41F 3E0F    MVI      A,15          ;INITIALIZE THE SECTOR TO READ
D421 323FD4  STA      NEWSEC
D424 2100BC  LXI      H,CCP-100H    ;AND THE DMA ADDRESS
D427 225ED4  SHLD     NEWDMA
D42A CD3ED4  CALL     WARMLOD        ;READ IN CP/M
D42D 0100C2  LXI      B,CCP+500H    ;LOAD ADDRESS FOR REST OF WARM BOOT
D430 CD12E4  CALL     DJDMA
D433 0E08    MVI      C,8
D435 CD0FE4  CALL     DJSEC
D438 CD72D4  CALL     WARMRD
D43B C303C2  JMP      CCP+503H

D43E 3E0F    WARMLOD MVI      A,15    ;PREVIOUS SECTOR
D43F =      NEWSEC  EQU      $-1

```

```

D440 3C          INR      A          ;UPDATE THE PREVIOUS SECTOR
D441 3C          INR      A
D442 FE1B        CPI      27         ;WAS IT THE LAST ?
D444 DA56D4      JC       NOWRAP
D447 D609        SUI      9          ;YES
D449 FE13        CPI      19
D44B C8          RZ
D44C 2A5ED4      LHL      NEWDMA
D44F 1180FB      LXI      D,-480H
D452 19          DAD      D
D453 225ED4      SHLD     NEWDMA
D456 323FD4      NOWRAP STA     NEWSEC      ;SAVE THE NEW SECTOR TO READ
D459 4F          MOV      C,A
D45A CD0FE4      CALL     DJSEC
D45D 2100BC      LXI      H,CCP-100H      ;GET THE PREVIOUS DMA ADDRESS
D45E =          NEWDMA EQU      $-2
D460 110001      LXI      D,100H          ;UPDATE THE DMA ADDRESS
D463 19          DAD      D
D464 225ED4      SHLD     NEWDMA          ;SAVE THE DMA ADDRESS
D467 44          MOV      B,H
D468 4D          MOV      C,L
D469 CD12E4      CALL     DJDMA          ;SET THE DMA ADDRESS
D46C CD72D4      CALL     WARMRD
D46F C33ED4      JMP      WARMLOD

```

```

D472 01000A      WARMRD LXI      B,RETURNS*100H+0;MAXIMUM # OF ERRORS
D475 C5          WRMREAD PUSH     B
D476 CD0CE4      CALL     DJTRK          ;SET THE TRACK
D479 CD15E4      CALL     DJREAD         ;READ THE SECTOR
D47C C1          POP      B
D47D D0          RNC                    ;CONTINUE IF SUCCESSFUL
D47E 05          DCR      B
D47F C275D4      JNZ      WRMREAD        ;KEEP TRYING
D482 C32AE4      JMP      DJERR

```

```

*****
*
* SETSEC JUST SAVES THE DESIRED SECTOR TO SEEK TO UNTIL AN
* ACTUAL READ OR WRITE IS ATTEMPTED.
*
*****

```

```

D485 79          SETSEC MOV      A,C          ;SAVE THE SECTOR NUMBER
D486 32E8D8      STA      CPMSEC          ;CP/M SECTOR #
D489 C9          RET

```

```

*****
*
* SETDMA SAVES THE DMA ADDRESS FOR THE DATA TRANSFER.
*
*****

```

```

D48A 60          SETDMA MOV      H,B          ;HL <- BC
D48B 69          MOV      L,C
D48C 22B5D5      SHLD     CPMDMA          ;CP/M DMA ADDRESS
D48F C9          RET

```

```
*****
*
* HOME IS TRANSLATED INTO A SEEK TO TRACK ZERO.
*
*****
```

```
D490 0E00    HOME    MVI    C,0                ;TRACK TO SEEK TO
```

```
*****
*
* SETTRK SAVES THE TRACK # TO SEEK TO. NOTHING IS DONE AT THIS
* POINT, EVERYTHING IS DEFERRED UNTIL A READ OR WRITE.
*
*****
```

```
D492 79      SETTRK  MOV    A,C                ;A <- TRACK #
D493 32EAD8   STA     CPMTRK                ;CP/M TRACK #
D496 C9      RET
```

```
*****
*
* SECTRAN TRANSLATES A LOGICAL SECTOR # INTO A PHYSICAL SECTOR
* #.
*
*****
```

```
D497 03      SECTRAN INX     B
D498 D5      PUSH    D                ;SAVE TABLE ADDRESS
D499 C5      PUSH    B                ;SAVE SECTOR #
D49A CD41D5  CALL    GETDPB           ;GET DPB ADDRESS INTO HL
D49D 7E      MOV     A,M              ;GET # OF CP/M SECTORS/TRACK
D49E B7      ORA     A                ;CLEAR CARY
D49F 1F      RAR     A                ;DIVIDE BY TWO
D4A0 91      SUB     C
D4A1 F5      PUSH    PSW              ;SAVE ADJUSTED SECTOR
D4A2 FAAED4  JM      SIDETWO
D4A5 F1      SIDEA   POP     PSW       ;DISCARD ADJUSTED SECTOR
D4A6 C1      POP     B                ;RESTORE SECTOR REQUESTED
D4A7 D1      POP     D                ;RESTOR ADDRESS OF XLT TABLE
D4A8 EB      SIDEONE XCHG             ;HL <- &(TRANSLATION TABLE)
D4A9 09      DAD     B                ;BC = OFFSET INTO TABLE
D4AA 6E      MOV     L,M              ;HL <- PHYSICAL SECTOR
D4AB 2600    MVI     H,0
D4AD C9      RET

D4AE 010F00  SIDETWO LXI     B,15      ;OFFSET TO SIDE BIT
D4B1 09      DAD     B
D4B2 7E      MOV     A,M
D4B3 E608    ANI     8                ;TEST FOR DOUBLE SIDED
D4B5 CAA5D4  JZ      SIDEA           ;MEDIA IS ONLY SINGLE SIDED
D4B8 F1      POP     PSW             ;RETRIEVE ADJUSTED SECTOR
D4B9 C1      POP     B
D4BA 2F      CMA
D4BB 3C      INR     A                ;MAKE SECTOR REQUEST POSITIVE
D4BC 4F      MOV     C,A              ;MAKE NEW SECTOR THE REQUESTED SECTOR
```



```

D4BD D1      POP      D
D4BE CDA8D4   CALL     SIDEONE
D4C1 3E80     MVI      A,80H      ;SIDE TWO BIT
D4C3 B5       ORA      L          ;      AND SECTOR
D4C4 6F       MOV      L,A
D4C5 C9       RET

```

```

*****
*
* SETDRV SELECTS THE NEXT DRIVE TO BE USED IN READ/WRITE
* OPERATIONS. IF THE DRIVE HAS NEVER BEEN SELECTED BEFORE, A
* PARAMETER TABLE IS CREATED WHICH CORRECTLY DESCRIBES THE
* DISKETTE CURRENTLY IN THE DRIVE. DISKETTES CAN BE OF FOUR
* DIFFERENT SECTOR SIZES:
*   1) 128 BYTES SINGLE DENSITY.
*   2) 256 BYTES DOUBLE DENSITY.
*   3) 512 BYTES DOUBLE DENSITY.
*   4) 1024 BYTES DOUBLE DENSITY.
*
*****

```

```

D4C6 79      SETDRV  MOV      A,C      ;SAVE THE DRIVE #
D4C7 32E9D8   STA      CPMDRV
D4CA FE04     CPI      MAXDISK      ;CHECK FOR A VALID DRIVE #
D4CC D23DD5   JNC      ZRET          ;ILLEGAL DRIVE #
D4CF 7B       MOV      A,E          ;TEST IF DRIVE EVER LOGGED IN BEFORE
D4D0 E601     ANI      1
D4D2 C224D5   JNZ      SETDRV1      ;BIT 0 OF E = 0 -> NEVER SELECTED BEFORE
D4D5 3E01     MVI      A,1          ;SELECT SECTOR 1 OF TRACK 1
D4D7 32EBD8   STA      TRUESEC
D4DA 32EAD8   STA      CPMTRK
D4DD CD20D6   CALL     FILL          ;FLUSH BUFFER AND REFILL
D4E0 DA3DD5   JC      ZRET          ;TEST FOR ERROR RETURN
D4E3 CD27E4   CALL     DJSTAT        ;GET STATUS ON CURRENT DRIVE
D4E6 E60C     ANI      0CH          ;STRIP OFF UNWANTED BITS
D4E8 F5       PUSH     PSW          ;USED TO SELECT A DPB
D4E9 1F       RAR
D4EA 215AD5   LXI      H,XLTS        ;TABLE OF XLT ADDRESSES
D4ED 5F       MOV      E,A
D4EE 1600     MVI      D,0
D4F0 19       DAD      D
D4F1 E5       PUSH     H            ;SAVE POINTER TO PROPER XLT
D4F2 CD41D5   CALL     GETDPB        ;GET DPH POINTER INTO DE
D4F5 EB       XCHG
D4F6 D1       POP      D
D4F7 0602     MVI      B,2          ;NUMBER OF BYTES TO MOVE
D4F9 CD37D6   CALL     MOVLOP        ;MOVE THE ADDRESS OF XLT
D4FC 110800   LXI      D,8          ;OFFSET TO DPB POINTER
D4FF 19       DAD      D            ;HL <- &DPH.DPB
D500 E5       PUSH     H
D501 2A07E0   LHLD     ORIGIN+7      ;GET ADDRESS OF DJ TERMINAL OUT ROUTINE
D504 23       INX      H            ;BUMP TO LOOK AT ADDRESS OF
                                   ;      UART STATUS LOCATION
D505 7E       MOV      A,M
D506 EE03     XRI      3            ;ADJUST FOR PROPER REV DJ
D508 6F       MOV      L,A

```

```

D509 26E3      MVI      H,(ORIGIN+300H)/100H
D50B 7E        MOV      A,M
D50C E608      ANI      DBLSID      ;CHECK DOUBLE SIDED BIT
D50E 1116D8    LXI      D,DPB128S   ;BASE FOR SINGLE SIDED DPB'S
D511 C217D5    JNZ      SIDEOK
D514 1156D8    LXI      D,DPB128D   ;BASE OF DOUBLE SIDED DPB'S
D517 EB        SIDEOK  XCHG         ;HL <- DBP BASE, DE <- &DPH.DPB
D518 D1        POP      D           ;RESTORE DE (POINTER INTO DPH)
D519 F1        POP      PSW        ;OFFSET TO CORRECT DPB
D51A 17        RAL
D51B 17        RAL
D51C 4F        MOV      C,A
D51D 0600      MVI      B,0
D51F 09        DAD      B
D520 EB        XCHG         ;PUT DPB ADDRESS IN DPH
D521 73        MOV      M,E
D522 23        INX      H
D523 72        MOV      M,D
D524 CD41D5    SETDRV1 CALL    GETDPB ;GET ADDRESS OF DPB IN HL
D527 010F00    LXI      B,15       ;OFFSET TO SECTOR SIZE
D52A 09        DAD      B
D52B 7E        MOV      A,M        ;GET SECTOR SIZE
D52C E607      ANI      7H
D52E 326ED5    STA      SECSIZ
D531 7E        MOV      A,M
D532 1F        RAR
D533 1F        RAR
D534 1F        RAR
D535 1F        RAR
D536 E60F      ANI      0FH
D538 32A4D5    STA      SECPSEC
D53B EB        XCHG         ;HL <- DPH
D53C C9        RET

D53D 210000    ZRET   LXI      H,0   ;SELDRV ERROR EXIT
D540 C9        RET

```

```

*****
*
* GETDPB RETURNS HL POINTING TO THE DPB OF THE CURRENTLY
* SELECTED DRIVE, DE POINTING TO DPH.
*
*****

```

```

D541 3AE9D8    GETDPB  LDA      CPMDRV ;GET DRIVE #
D544 6F        MOV      L,A        ;FORM OFFSET
D545 2600      MVI      H,0
D547 29        DAD      H
D548 29        DAD      H
D549 29        DAD      H
D54A 29        DAD      H
D54B 1196D8    LXI      D,DPZERO   ;BASE OF DPH'S
D54E 19        DAD      D
D54F E5        PUSH     H          ;SAVE ADDRESS OF DPH
D550 110A00    LXI      D,10      ;OFFSET TO DPB
D553 19        DAD      D

```

```

D554 7E      MOV      A,M          ;GET LOW BYTE OF DPB ADDRESS
D555 23      INX       H
D556 66      MOV      H,M          ;GET LOW BYTE OF DPB
D557 6F      MOV      L,A
D558 D1      POP       D
D559 C9      RET

```

```

*****
*
* XLTS IS A TABLE OF ADDRESS THAT POINT TO EACH OF THE XLT
* TABLES FOR EACH SECTOR SIZE.
*
*****

```

```

D55A 48D7    XLTS     DW      XLT128      ;XLT FOR 128 BYTE SECTORS
D55C 63D7    DW      XLT256      ;XLT FOR 256 BYTE SECTORS
D55E 98D7    DW      XLT512      ;XLT FOR 512 BYTE SECTORS
D560 D5D7    DW      XLT124      ;XLT FOR 1024 BYTE SECTORS

```

```

*****
*
* WRITE ROUTINE MOVES DATA FROM MEMORY INTO THE BUFFER. IF THE
* DESIRED CP/M SECTOR IS NOT CONTAINED IN THE DISK BUFFER, THE
* BUFFER IS FIRST FLUSHED TO THE DISK IF IT HAS EVER BEEN
* WRITTEN INTO, THEN A READ IS PERFORMED INTO THE BUFFER TO GET
* THE DESIRED SECTOR. ONCE THE CORRECT SECTOR IS IN MEMORY, THE
* BUFFER WRITTEN INDICATOR IS SET, SO THE BUFFER WILL BE
* FLUSHED, THEN THE DATA IS TRANSFERRED INTO THE BUFFER.
*
*****

```

```

D562 79      WRITE    MOV      A,C          ;SAVE WRITE COMMAND TYPE
D563 32CCD5   STA      WRITTP
D566 3E01     MVI      A,1          ;SET WRITE COMMAND
D568 06       DB       (MVI) OR (B*8) ;THIS "MVI B" INSTRUCTION CAUSES
;          THE FOLLOWING "XRA A" TO
;          BE SKIPPED OVER.

```

```

*****
*
* READ ROUTINE TO BUFFER DATA FROM THE DISK. IF THE SECTOR
* REQUESTED FROM CP/M IS IN THE BUFFER, THEN THE DATA IS SIMPLY
* TRANSFERRED FROM THE BUFFER TO THE DESIRED DMA ADDRESS. IF
* THE BUFFER DOES NOT CONTAIN THE DESIRED SECTOR, THE BUFFER IS
* FLUSHED TO THE DISK IF IT HAS EVER BEEN WRITTEN INTO, THEN
* FILLED WITH THE SECTOR FROM THE DISK THAT CONTAINS THE
* DESIRED CP/M SECTOR.
*
*****

```

```

D569 AF      READ     XRA      A          ;SET THE COMMAND TYPE TO READ
D56A 32B8D5   STA      RDWR          ;SAVE COMMAND TYPE

```

```

*****
*
* REDWRT CALCULATES THE PHYSICAL SECTOR ON THE DISK THAT
*
*****

```

```

* CONTAINS THE DESIRED CP/M SECTOR, THEN CHECKS IF IT IS THE
* SECTOR CURRENTLY IN THE BUFFER. IF NO MATCH IS MADE, THE
* BUFFER IS FLUSHED IF NECESSARY AND THE CORRECT SECTOR READ
* FROM THE DISK.
*
*****

```

```

D56D 0600 REDWRT MVI B,0 ;THE 0 IS MODIFIED TO CONTAIN THE LOG2
D56E = SECSIZ EQU $-1 ; OF THE PHYSICAL SECTOR SIZE/128
; ON THE CURRENTLY SELECTED DISK.

D56F 3AE8D8 LDA CPMSEC ;GET THE DESIRED CP/M SECTOR #
D572 F5 PUSH PSW ;TEMPORARY SAVE
D573 E680 ANI 30H ;SAVE ONLY THE SIDE BIT
D575 4F MOV C,A ;REMEMBER THE SIDE
D576 F1 POP PSW ;GET THE SECTOR BACK
D577 E67F ANI 7FH ;FORGET THE SIDE BIT
D579 3D DCR A ;TEMPORARY ADJUSTMENT
D57A 05 DIVLOOP DCR B ;UPDATE REPEAT COUNT
D57B CA83D5 JZ DIVDONE
D57E B7 ORA A ;CLEAR THE CARY FLAG
D57F 1F RAR ;DIVIDE THE CP/M SECTOR # BY THE SIZE
; OF THE PHYSICAL SECTORS
;

D580 C37AD5 JMP DIVLOOP
D583 3C DIVDONE INR A
D584 B1 ORA C ;RESTORE THE SIDE BIT
D585 32EBD8 STA TRUESEC ;SAVE THE PHYSICAL SECTOR NUMBER
D588 21E9D8 LXI H,CPMDRV ;POINTER TO DESIRED DRIVE,TRACK, AND SECTOR
D58B 11ECD8 LXI D,BUFDRV ;POINTER TO BUFFER DRIVE,TRACK, AND SECTOR
D58E 0604 MVI B,4 ;COUNT LOOP
D590 05 DTSLOP DCR B ;TEST IF DONE WITH COMPARE
D591 CA9FD5 JZ MOVE ;YES, MATCH. GO MOVE THE DATA
D594 1A LDAX D ;GET A BYTE TO COMPARE
D595 BE CMP M ;TEST FOR MATCH
D596 23 INX H ;BUMP POINTERS TO NEXT DATA ITEM
D597 13 INX D
D598 CA90D5 JZ DTSLOP ;MATCH, CONTINUE TESTING

```

```

*****
*
* DRIVE, TRACK, AND SECTOR DON'T MATCH, FLUSH THE BUFFER IF
* NECESSARY AND THEN REFILL.
*
*****

```

```

D59B CD20D6 CALL FILL ;FILL THE BUFFER WITH CORRECT PHYSICAL SECTOR
D59E D8 RC ;NO GOOD, RETURN WITH ERROR INDICATION

```

```

*****
*
* MOVE HAS BEEN MODIFIED TO CAUSE EITHER A TRANSFER INTO OR OUT
* THE BUFFER.
*
*****

```

```

D59F 3AE8D8 MOVE LDA CPMSEC ;GET THE CP/M SECTOR TO TRANSFER
D5A2 3D DCR A ;ADJUST TO PROPER SECTOR IN BUFFER

```

```

D5A3 E600      ANI      0      ;STRIP OFF HIGH ORDERED BITS
D5A4 =          SECPSEC EQU    $-1 ;THE 0 IS MODIFIED TO REPRESENT THE # OF
                                   ; CP/M SECTORS PER PHYSICAL SECTORS
D5A5 6F         MOV     L,A     ;PUT INTO HL
D5A6 2600      MVI     H,0
D5A8 29         DAD     H       ;FORM OFFSET INTO BUFFER
D5A9 29         DAD     H
D5AA 29         DAD     H
D5AB 29         DAD     H
D5AC 29         DAD     H
D5AD 29         DAD     H
D5AE 29         DAD     H
D5AF 11EFD8    LXI     D,BUFFER ;BEGINNING ADDRESS OF BUFFER
D5B2 19         DAD     D       ;FORM BEGINNING ADDRESS OF SECTOR TO TRANSFER
D5B3 EB        XCHG          ;DE = ADDRESS IN BUFFER
D5B4 210000    LXI     H,0      ;GET DMA ADDRESS, THE 0 IS MODIFIED TO
                                   ; CONTAIN THE DMA ADDRESS

D5B5 =          CPMDMA EQU    $-2
D5B7 3E00      MVI     A,0      ;THE ZERO GETS MODIFIED TO CONTAIN
                                   ; A ZERO IF A READ, OR A 1 IF WRITE

D5B8 =          RDWR     EQU    $-1
D5B9 A7         ANA     A       ;TEST WHICH KIND OF OPERATION
D5BA C2C2D5    JNZ     INTO     ;TRANSFER DATA INTO THE BUFFER
D5BD CD35D6    OUTOF  CALL    MOVER
D5C0 AF        XRA     A
D5C1 C9        RET

D5C2 EB        INTO    XCHG          ;
D5C3 CD35D6    CALL    MOVER        ;MOVE THE DATA, HL = DESTINATION
                                   ; DE = SOURCE

D5C6 3E01      MVI     A,1
D5C8 32D5D5    STA     BUFWRN      ;SET BUFFER WRITTEN INTO FLAG
D5CB 3E00      MVI     A,0      ;CHECK FOR DIRECTORY WRITE
D5CC =          WRITTP EQU    $-1
D5CD 3D        DCR     A
D5CE 3E00      MVI     A,0
D5D0 32CCD5    STA     WRITTP      ;SET NO DIRECTORY WRITE
D5D3 C0        RNZ              ;NO ERROR EXIT

```

```

*****
*
* FLUSH WRITES THE CONTENTS OF THE BUFFER OUT TO THE DISK IF
* IT HAS EVER BEEN WRITTEN INTO.
*
*****

```

```

D5D4 3E00      FLUSH  MVI     A,0      ;THE 0 IS MODIFIED TO REFLECT IF
                                   ; THE BUFFER HAS BEEN WRITTEN INTO

D5D5 =          BUFWRN EQU    $-1
D5D6 A7         ANA     A       ;TEST IF WRITTEN INTO
D5D7 C8         RZ              ;NOT WRITTEN, ALL DONE
D5D8 2118E4    LXI     H,DJWRITE ;WRITE OPERATION

```

```

*****
*
* PREP PREPARES TO READ/WRITE THE DISK. RETRIES ARE ATTEMPTED.
*

```

```

* UPON ENTRY, H&L MUST CONTAIN THE READ OR WRITE OPERATION
* ADDRESS.
*
*****

```

```

D5DB AF      PREP      XRA      A          ;RESET BUFFER WRITTEN FLAG
D5DC 32D5D5      STA      BUFWRTN
D5DF 2212D6      SHLD     RETRYOP      ;SET UP THE READ/WRITE OPERATION
D5E2 060A      MVI      B,RETRIES      ;MAXIMUM NUMBER OF RETRIES TO ATTEMPT
D5E4 C5      RETRYLP   PUSH     B      ;SAVE THE RETRY COUNT
D5E5 3AECDD8     LDA      BUFDVR      ;GET DRIVE NUMBER INVOLVED IN THE OPERATION
D5E8 4F      MOV      C,A
D5E9 CD33D3      CALL     DJDRV      ;SELECT THE DRIVE
D5EC 3AEDD8     LDA      BUFTKR
D5EF A7      ANA      A          ;TEST FOR TRACK ZERO
D5F0 4F      MOV      C,A
D5F1 C5      PUSH     B
D5F2 CC09E4     CZ      DJHOME      ;HOME THE DRIVE IF TRACK 0
D5F5 C1      POP      B          ;RESTORE TRACK #
D5F6 CD0CE4     CALL     DJTRK      ;SEEK TO PROPER TRACK
D5F9 3AEED8     LDA      BUFSEC      ;GET SECTOR INVOLVED IN OPERATION
D5FC F5      PUSH     PSW          ;SAVE THE SECTOR #
D5FD 07      RLC          ;BIT 0 OF A EQUALS SIDE #
D5FE E601     ANI      1          ;STRIP OFF UNNECESSARY BITS
D600 4F      MOV      C,A          ;C <- SIDE #
D601 CD30E4     CALL     DJSIDE      ;SELECT THE SIDE
D604 F1      POP      PSW          ;A <- SECTOR #
D605 E67F     ANI      7FH        ;STRIP OFF SIDE BIT
D607 4F      MOV      C,A          ;C <- SECTOR #
D608 CD0FE4     CALL     DJSEC      ;SET THE SECTOR TO TRANSFER
D60B 01EFD8     LXI      B,BUFFER   ;SET THE DMA ADDRESS
D60E CD12E4     CALL     DJDMA
D611 CD15E4     CALL     DJREAD      ;THE READ OPERATION IS MODIFIED TO WRITE
D612 =      RETRYOP   EQU      $-2
D614 C1      POP      B          ;RESTORE THE RETRY COUNTER
D615 3E00     MVI      A,0        ;NO ERROR EXIT STATUS
D617 D0      RNC          ;RETURN NO ERROR
D618 05      DCR      B          ;UPDATE THE RETRY COUNTER
D619 37      STC          ;ASSUME RETRY COUNT EXPIRED
D61A 3EFF     MVI      A,0FFH      ;ERROR RETURN
D61C C8      RZ
D61D C3E4D5     JMP      RETRYLP    ;TRY AGAIN

```

```

*****
*
* FILL FILLS THE BUFFER WITH A NEW SECTOR FROM THE DISK.
*
*****

```

```

D620 CDD4D5     FILL     CALL     FLUSH      ;FLUSH BUFFER FIRST
D623 D3      RC          ;CHECK FOR ERROR
D624 11E9D8     LXI      D,CPMDRV      ;UPDATE THE DRIVE, TRACK, AND SECTOR
D627 21ECD8     LXI      H,BUFDVR
D62A 0603     MVI      B,3          ;NUMBER OF BYTES TO MOVE
D62C CD37D6     CALL     MOVLOP      ;COPY THE DATA
D62F 2115E4     LXI      H,DJREAD

```

```

D632 C3DBD5      JMP      PREP          ;SELECT DRIVE, TRACK, AND SECTOR.
                                   ;      THEN READ THE BUFFER

```

```

*****
*
* MOVER MOVES 128 BYTES OF DATA. SOURCE POINTER IN DE, DEST
* POINTER IN HL.
*
*****

```

```

D635 0680      MOVER  MVI      B,128      ;LENGTH OF TRANSFER
D637 1A        MOVLOP LDAX     D           ;GET A BTE OF SOURCE
D638 77        MOVLOP MOV      M,A        ;MOVE IT
D639 13        MOVLOP INX      D         ;BUMP POINTERS
D63A 23        MOVLOP INX      H
D63B 05        MOVLOP DCR      B         ;UPDATE COUNTER
D63C C237D6    MOVLOP JNZ      MOVLOP     ;CONTINUE MOVING UNTIL DONE
D63F C9        MOVLOP RET

```

```

*****
*
* TERMINAL DRIVER ROUTINES. IOBYTE IS INITIALIZED BY THE COLD
* BOOT ROUTINE, TO MODIFY, CHANGE THE "INTIOBY" EQUATE. THE
* I/O ROUTINES THAT FOLLOW ALL WORK EXACTLY THE SAME WAY. USING
* IOBYTE, THEY OBTAIN THE ADDRESS TO JUMP TO IN ORDER TO EXECUTE
* THE DESIRED FUNCTION. THERE IS A TABLE WITH FOUR ENTRIES FOR
* EACH OF THE POSSIBLE ASSIGNMENTS FOR EACH DEVICE. TO MODIFY
* THE I/O ROUTINES FOR A DIFFERENT I/O CONFIGURATION, JUST
* CHANGE THE ENTRIES IN THE TABLES.
*
*****

```

```

E403 =          CITYY  EQU      DJCIN      ;INPUT FROM THE DISK JOCKEY 2D
E406 =          COTTY  EQU      DJCOUT     ;OUTPUT TO THE DISK JOCKEY 2D

```

```

*****
*
* CONST: GET THE STATUS FOR THE CURRENTLY ASSIGNED CONSOLE
* DEVICE. THE CONSOLE DEVICE CAN BE GOTTEN FROM IOBYTE,
* THEN A JUMP TO THE CORRECT CONSOLE STATUS ROUTINE IS
* PERFORMED.
*
*****

```

```

D640 21BAD6    CONST  LXI      H,CSTBLE   ;BEGINNING OF JUMP TABLE
D643 C352D6    CONST  JMP      CONIN1    ;SELECT CORRECT JUMP

```

```

*****
*
* CSREADER: IF THE CONSOLE IS ASSIGNED TO THE READER THEN A
* JUMP WILL BE MADE HERE, WHERE ANOTHER JUMP WILL
* OCCUR TO THE CORRECT READER STATUS.
*
*****

```

```

D646 21C2D6    CSREADR LXI      H,CSRTBLE ;BEGINNING OF READER STATUS TABLE

```

TERMINAL DRIVERS

D649 C36FD6 JMP READERA

```

*****
*
* CONIN: TAKE THE CORRECT JUMP FOR THE CONSOLE INPUT ROUTINE.
* THE JUMP IS BASED ON THE TWO LEAST SIGNIFICANT BITS OF
* IOBYTE.
*
*****

```

```

D64C CDD4D5 CONIN CALL FLUSH ;FLUSH THE DISK BUFFER
D64F 2192D6 LXI H,CITBLE ;BEGINNING OF CHARACTER INPUT TABLE

```

```

*
* ENTRY AT CONIN1 WILL DECODE THE TWO LEAST SIGNIFICANT BITS
* OF IOBYTE. THIS IS USED BY CONIN,CONOUT, AND CONST.
*

```

```

D652 3A0300 CONIN1 LDA IOBYTE
D655 17 RAL

```

```

*
* ENTRY AT SELDEV WILL FORM AN OFFSET INTO THE TABLE POINTED
* TO BY H&L AND THEN PICK UP THE ADDRESS AND JUMP THERE.
*

```

```

D656 E606 SELDEV ANI 6H ;STRIP OFF UNWANTED BITS
D658 1600 MVI D,0 ;FORM OFFSET
D65A 5F MOV E,A
D65B 19 DAD D ;ADD OFFSET
D65C 7E MOV A,M ;PICK UP HIGH BYTE
D65D 23 INX H
D65E 66 MOV H,M ;PICK UP LOW BYTE
D65F 6F MOV L,A ;FORM ADDRESS
D660 E9 PCHL ;GO THERE !

```

```

*****
*
* CONOUT: TAKE THE PROPER BRANCH ADDRESS BASED ON THE TWO LEAST
* SIGNIFICANT BITS OF IOBYTE.
*
*****

```

```

D661 C5 CONOUT PUSH B ;SAVE THE CHARACTER
D662 CDD4D5 CALL FLUSH ;FLUSH THE DISK BUFFER
D665 C1 POP B ;RESTORE THE CHARACTER
D666 219AD6 LXI H,COTBLE ;BEGINNING OF THE CHARACTER OUT TABLE
D669 C352D6 JMP CONIN1 ;DO THE DECODE

```

```

*****
*
* READER: SELECT THE CORRECT READER DEVICE FOR INPUT. THE
* READER IS SELECTED FROM BITS 2 AND 3 OF IOBYTE.
*
*****

```



D66C 21B2D6      READER   LXI      H,RTBLE                    ;BEGINNING OF READER INPUT TABLE

\*  
\* ENTRY AT READERA WILL DECODE BITS 2 & 3 OF IOBYTE, USED  
\* BY CSREADER.  
\*

D66F 3A0300      READERA LDA      IOBYTE

\*  
\* ENTRY AT READER1 WILL SHIFT THE BITS INTO POSITION, USED  
\* BY LIST AND PUNCH.  
\*

D672 1F           READR1   RAR  
D673 C356D6           JMP      SELDEV

\*\*\*\*\*  
\*  
\* PUNCH: SELECT THE CORRECT PUNCH DEVICE. THE SELECTION COMES  
\* FROM BITS 4&5 OF IOBYTE.  
\*  
\*\*\*\*\*

D676 21AAD6      PUNCH   LXI      H,PTBLE                    ;BEGINNING OF PUNCH TABLE  
D679 3A0300           LDA      IOBYTE

\*  
\* ENTRY AT PNCH1 ROTATES BITS A LITTLE MORE IN PREP FOR  
\* SELDEV, USED BY LIST.  
\*

D67C 1F           PNCH1   RAR  
D67D 1F                  RAR  
D67E C372D6                  JMP      READR1

\*\*\*\*\*  
\*  
\* LIST: SELECT A LIST DEVICE BASED ON BITS 6&7 OF IOBYTE  
\*  
\*\*\*\*\*

D681 21A2D6      LIST    LXI      H,LTBLE                    ;BEGINNING OF THE LIST DEVICE ROUTINES  
D684 3A0300      LIST1   LDA      IOBYTE  
D687 1F                  RAR  
D688 1F                  RAR  
D689 C37CD6                  JMP      PNCH1

\*\*\*\*\*  
\*  
\* LISTST: GET THE STATUS OF THE CURRENTLY ASSIGNED LIST DEVICE  
\*  
\*\*\*\*\*

D68C 21CAD6      LISTST   LXI      H,LSTBLE                    ;BEGINNING OF THE LIST DEVICE STATUS  
D68F C384D6           JMP      LIST1

\*\*\*\*\*  
 \*  
 \* IF CUSTOMIZING I/O ROUTINES IS BEING PERFORMED, THE TABLE  
 \* BELOW SHOULD BE MODIFIED TO REFLECT THE CHANGES. ALL I/O  
 \* DEVICES ARE DECODED OUT OF IOBYTE AND THE JUMP IS TAKEN FROM  
 \* THE FOLLOWING TABLES.  
 \*  
 \*\*\*\*\*

\*  
 \* CONSOLE INPUT TABLE  
 \*

			<u>Value</u>		
D692 00D7	CITBLE	DW	CIUCL	0	;INPUT FROM USER CONSOLE 1 (CURRENTLY ; SWBD PARALLEL PORT 4) <i>KYBD</i>
D694 15D7		DW	CICRT	1	;INPUT FROM CRT (CURRENTLY SWITCHBOARD ; SERIAL PORT 1) <i>DIABLO</i>
D696 6CD6		DW	READER	2	;INPUT FROM READER (DEPENDS ON READER ; SELECTION)
D693 03E4		DW	CITTY	3	;INPUT FROM TTY (CURRENTLY INPUT FROM ; DISK JOCKEY 2D)

\*  
 \* CONSOLE OUTPUT TABLE  
 \*

D69A D2D6	COTBLE	DW	COCRT	0	;OUTPUT TO CRT (MSDV) <i>CRT</i>
D69C D2D6		DW	COCRT	1	;OUTPUT TO CRT (MSDV) <i>CRT</i>
D69E 81D6		DW	LIST	2	;OUTPUT TO LIST DEVICE (DEPENDS ON ; BITS 6&7 OF IOBYTE) <i>LIST</i>
D6A0 06E4		DW	COTTY	3	;OUTPUT TO TTY (CURRENTLY OUTPUT TO ; DISK JOCKEY 2D) <i>DJ</i>

\*  
 \* LIST DEVICE TABLE  
 \*

D6A2 06E4	LTBLE	DW	COTTY	0	;OUTPUT TO TTY (CURRENTLY ASSIGNED ; BY INTIOBY, OUTPUT TO 2D)
D6A4 D6D8		DW	COPTR	1	;OUTPUT TO PRINTER
D6A6 D6D6		DW	COLPT	2	;OUTPUT TO LINE PRINTER (CURRENTLY ; SWITCHBOARD SERIAL PORT 1)
D6A8 E1D6		DW	COUL1	3	;OUTPUT TO USER LINE PRINTER 1 (CURRENTLY ; SWITCHBOARD SERIAL PORT 1)

\*  
 \* PUNCH DEVICE TABLE  
 \*

D6AA 06E4	PTBLE	DW	COTTY		;OUTPUT TO THE TTY (CURRENTLY ASSIGNED ; BY INTIOBY, OUTPUT TO 2D)
D6AC D6D8		DW	COPTR		;OUTPUT TO PRINTER

D6AE D6D6	DW	COUP1	;OUTPUT TO USER PUNCH 1 (CURRENTLY
			; SWITCHBOARD SERIAL PORT 1)
D6B0 D6D6	DW	COUP2	;OUTPUT TO USER PUNCH 2 (CURRNTLLY
			; SWITCHBOARD SERIAL PORT 1)

\*  
\* READER DEVICE INPUT TABLE  
\*

D6B2 03E4	RTBLE DW	CITTY	;INPUT FROM TTY (CURRENTLY ASSIGNED
			; BY INTIOBY, INPUT FROM 2D)
D6B4 15D7	DW	CIPTR	;INPUT FROM PAPER TAPE READER (CURRENTLY
			; SWITCHBOARD SERIAL PORT 1)
D6B6 15D7	DW	CIUR1	;INPUT FROM USER READER 1 (CURRENTLY
			; SWITCHBOARD SERIAL PORT 1)
D6B8 15D7	DW	CIUR2	;INPUT FROM USER READER 2 (CURRENTLY
			; SWITCHBOARD SERIAL PORT 1)

\*  
\* CONSOLE STATUS TABLE  
\*

D6BA 0CD7	CSTBLE DW	CSUC1	;STATUS FROM SWBD PARALLEL PORT 4, AS
			; READ FROM ATTN BIT 0)
D6BC 29D7	DW	CSCRT	;STATUS FROM CRT (CURRENTLY SWITCHBOARD
			; SERIAL PORT 1)
D6BE 46D6	DW	CSREADR	;STATUS FROM READER (DEPENDS ON READER DEVICE )
			;
D6C0 21D7	DW	CSTTY	;STATUS OF TTY (CURRENTLY STSTUS FROM
			; DISK JOCKEY 2D)

\*  
\* STATUS FROM READER DEVICE  
\*

D6C2 21D7	CSRTBLE DW	CSTTY	;STATUS FROM TTY (CURRENTLY ASSIGNED
			; BY INTIOBY, STATUS OF 2D)
D6C4 29D7	DW	CSPTR	;STATUS FROM PAPER TAPE READER (CURRENTLY
			; SWITCHBOARD SERIAL PORT 1)
D6C6 29D7	DW	CSUR1	;STATUS FROM USER READER 1 (CURRENTLY
			; SWITCHBOARD SERIAL PORT 1)
D6C8 29D7	DW	CSUR2	;STATUS OF USER READER 2 (CURRENTLY
			; SWITCHBOARD SERIAL PORT 1)

\*  
\* STATUS FROM LIST DEVICE  
\*

D6CA 37D7	LSTBLE DW	READY	;CONSOLE ALWAYS READY
D6CC 37D7	DW	READY	;GET LIST STATUS
D6CE 32D7	DW	LSLPT	
D6D0 32D7	DW	LSLPT	

\*\*\*\*\*  
\*  
\* ROUTINES FOR MY SYSTEM. J. J. O'BRIEN  
\*

\*\*\*\*\*

\*  
\* MSDV VIDEO DRIVER  
\*

D6D2 79	COCRT	MOV	A,C	;MSDV WANTS DATA IN A
D6D3 C300E8		JMP	MSDV	;GO THERE

\*  
\*\*\*\*\*  
\*\* THE FOLLOWING EQUATES SET OUTPUT DEVICE TO OUTPUT TO THE  
\* SWITCHBOARD SERIAL PORT 1.  
\*

\*\*\*\*\*

D6D6 =	COPTP	EQU	\$	;OUTPUT FROM PAPER TAPE PUNCH
D6D6 =	COUP1	EQU	\$	;OUTPUT FROM USER PUNCH 1
D6D6 =	COUP2	EQU	\$	;OUTPUT FROM USER PUNCH 2
D6D6 DB02	COLPT	IN	2	;OUTPUT FROM LINE PRINTER,GET STATUS
D6D8 E680		ANI	80H	;WAIT UNTIL OK TO SEND
D6DA CAD6D6		JZ	COLPT	
D6DD 79		MOV	A,C	;OUTPUT THE CHARACTER
D6DE D301		OUT	1	
D6E0 C9		RET		

\*\*\*\*\*  
\*  
\* CUSTOM I/O PRINTER DRIVER FOR DIABLO PRINTER WITH 1200 BAUD  
\* ETX/ACK HANDSHAKE.  
\*  
\*\*\*\*\*

D6E1 CDD6D6	COUL1	CALL	COLPT	;OUTPUT THE CHARACTER
D6E4 3AFFD6		LDA	COUNT	
D6E7 3D		DCR	A	
D6E8 32FFD6		STA	COUNT	
D6EB C0		RNZ		
D6EC 3E4E		MVI	A,78	
D6EE 32FFD6		STA	COUNT	
D6F1 0E03		MVI	C,AETX	
D6F3 CDD6D6		CALL	COLPT	
D6F6 CD15D7	PWAIT	CALL	CIPTR	
D6F9 FE06		CPI	AACK	
D6FB C2F6D6		JNZ	PWAIT	
D6FE C9		RET		

D6FF 32	COUNT	DB	50
---------	-------	----	----

\*\*\*\*\*  
\*  
\* THE FOLLOWING EQUATES SET THE INPUT TO COME FROM THE SWBD  
\* PARALLEL PORT 4, WITH STATUS ON ATTENTION PORT BIT 0.  
\*  
\*\*\*\*\*

COCRT

COLPT  
be

COUL1

\*\*\*\*\*

```

D700 DB03      CIUC1  IN      3      ;GET ATTENTION BYTE
D702 E601      ANI      1      ;GET BIT 0 ONLY
D704 CA00D7    JZ       CIUC1    ;WAIT FOR CHARACTER
D707 DB04      IN      4      ;GET CHARACTER
D709 E67F      ANI      7FH     ;STRIP OFF THE PARITY
D70B C9        RET

```

```

D70C DB03      CSUC1  IN      3      ;GET ATTENTION BYTE
D70E E601      ANI      1      ;GET BIT 0 ONLY
D710 EE01      XRI      1      ;CHANGE POLARITY
D712 C324D7    JMP      STAT     ;RETURN PROPER INDICATION

```

\*\*\*\*\*

```

*
* THE FOLLOWING EQUATES SET THE INPUT FROM THE DEVICES TO COME
* FROM THE SWITCHBOARD SERIAL PORT 1.
*

```

\*\*\*\*\*

```

D715 =          CICRT  EQU      $      ;INPUT FROM CRT
D715 =          CIUR1  EQU      $      ;INPUT FROM USER READER 1
D715 =          CIUR2  EQU      $      ;INPUT FROM USER READER 2
D715 DB02      CIPTR  IN      2      ;INPUT FROM PAPER TAPE READER, GET STATUS
D717 E640      ANI      40H     ;WAIT FOR CHARACTER
D719 CA15D7    JZ       CIPTR
D71C DB01      IN      1
D71E E67F      ANI      7FH     ;STRIP OFF THE PARITY
D720 C9        RET

```

\*\*\*\*\*

```

*
* CONSOLE STATUS ROUTINES, TEST IF A CHARACTER HAS ARRIVED.
*

```

\*\*\*\*\*

```

D721 CD21E4    CSTTY  CALL     DJTSTAT ;STATUS FROM DISK JOCKEY 2D
D724 3E00      STAT  MVI      A,0     ;PREP FOR ZERO RETURN
D726 C0        RNZ
D727 3D        DCR      A           ;NOTHING FOUND
D728 C9        RET                ;RETURN WITH 0FFH

```

\*\*\*\*\*

```

*
* THE FOLLOWING EQUATES CAUSE THE DEVICES TO GET STATUS FROM
* THE SWITCHBOARD SERIAL PORT 1.
*

```

\*\*\*\*\*

```

D729 =          CSUR1  EQU      $      ;STATUS OF USER READER 1
D729 =          CSUR2  EQU      $      ;STATUS OF USER READER 2
D729 =          CSPTR  EQU      $      ;STATUS OF PAPER TAPE READER
D729 DB02      CSCRT  IN      2      ;STATUS FROM CRT, GET STATUS
D72B E640      ANI      40H     ;STRIP OF DATA READY BIT
D72D EE40      XRI      40H     ;MAKE CORRECT POLARITY

```

D72F C324D7 JMP STAT ;RETURN PROPER INDICATION

```
*****
*
* LIST DEVICE STATUS ROUTINES.
*
*****
```

D732 DB02 LSLPT IN 2 ;ALL OTHER DEVICES WAIT  
 D734 E680 ANI 80H  
 D736 C8 RZ  
 D737 3EFF READY MVI A,0FFH  
 D739 C9 RET

```
*****
*
* THIS INITIALIZING ROUTINE SAMPLES BIT 0 OF SWBD PORT 7 TO
* DETERMINE IF THE KEYBOARD IS PLUGGED IN. IF THE KEYBOARD IS
* PLUGGED IN, THE LSB RETURNS A 0. OTHERWISE, IT IS A 1.
* THIS 1 IS ADDED TO IOBYTE TO CHANGE THE CONSOLE INPUT FROM
* THE SWBD PARALLEL PORT 4 (THE KEYBOARD) TO THE SWBD SERIAL
* PORT THAT RECEIVES RS232 DATA FROM THE RS232 TERMINAL.
*
*****
```

D73A 0E19 TINIT MVI C,CLEAR ;INITIALIZE THE TERMINAL ROUTINE  
 D73C DB07 IN 7 ;GET KEYBOARD INTERLOCK BYTE  
 D73E E601 ANI 1 ;GET BIT 1 ONLY  
 D740 C6C0 ADI INTIOBY ;ADD INTIOBY TO KEYBOARD BIT  
 D742 320300 STA IOBYTE ;INITIALIZE IOBYTE  
 D745 C30CD3 JMP COUT

```
*****
*
* XLT TABLES (SECTOR SKEW TABLES) FOR CP/M 2.0. THESE TABLES
* DEFINE THE SECTOR TRANSLATION THAT OCCURS WHEN MAPPING CP/M
* SECTORS TO PHYSICAL SECTORS ON THE DISK. THERE IS ONE SKEW
* TABLE FOR EACH OF THE POSSIBLE SECTOR SIZES. CURRENTLY THE
* TABLES ARE LOCATED ON TRACK 0 SECTORS 6 AND 8. THEY ARE
* LOADED INTO MEMORY IN THE CBIOS RAM BY THE COLD BOOT ROUTINE.
*
*****
```

D748 00 XLT128 DB 0  
 D749 01070D1319 DB 1,7,13,19,25  
 D74E 050B1117 DB 5,11,17,23  
 D752 03090F15 DB 3,9,15,21  
 D756 02080E141A DB 2,8,14,20,26  
 D75B 060C1218 DB 6,12,18,24  
 D75F 040A1016 DB 4,10,16,22

D763 00 XLT256 DB 0  
 D764 0102131425 DB 1,2,19,20,37,38  
 D76A 0304151627 DB 3,4,21,22,39,40  
 D770 0506171829 DB 5,6,23,24,41,42  
 D776 0708191A2B DB 7,8,25,26,43,44

EXCEPT  
 COUT AT 58DB

END OF TERMINAL DRIVERS

TINIT MVI C, '

D77C	090A1B1C2D	DB	9,10,27,28,45,46
D782	0B0C1D1E2F	DB	11,12,29,30,47,48
D788	0D0E1F2031	DB	13,14,31,32,49,50
D78E	0F10212233	DB	15,16,33,34,51,52
D794	11122324	DB	17,18,35,36

D7D5	00	XLT124	DB	0
D7D6	0102030405		DB	1,2,3,4,5,6,7,8
D7DE	191A1B1C1D		DB	25,26,27,28,29,30,31,32
D7E6	3132333435		DB	49,50,51,52,53,54,55,56
D7EE	090A0B0C0D		DB	9,10,11,12,13,14,15,16
D7F6	2122232425		DB	33,34,35,36,37,38,39,40
D7FE	393A3B3C3D		DB	57,58,59,60,61,62,63,64
D806	1112131415		DB	17,18,19,20,21,22,23,24
D80E	292A2B2C2D		DB	41,42,43,44,45,46,47,48

```
*****
*
* THE FOLLOWING DPB DEFINES A DISKETTE FOR 128 BYTE SECTORS,
* SINGLE DENSITY, AND SINGLE SIDED.
*
*****
```

Device	Format	Size	Units	Notes
D816	1A00	DW	26	;CP/M SECTORS/TRACK
D818	03	DB	3	;BSH
D819	07	DB	7	;BLM
D81A	00	DB	0	;EXM
D81B	F200	DW	242	;DSM
D81D	3F00	DW	63	;DRM
D81F	C0	DB	0C0H	;AL0
D820	00	DB	0	;AL1
D821	1000	DW	16	;CKS
D823	0200	DW	2	;OFF
D825	01	DB	1H	;16*((#CPM SECTORS/PHYSICAL SECTOR) -1) + ;LOG2(#BYTES PER SECTOR/128) + 1 + ;8 IF DOUBLE SIDED.

```

*****
*
* THE FOLLOWING DPB DEFINES A DISKETTE FOR 256 BYTE SECTORS,
* DOUBLE DENSITY, AND SINGLE SIDED.
*
*****

```

```

D826 3400 DPB256S DW      52      ;CP/M SECTORS/TRACK
D828 04    DB      4          ;BSH
D829 0F    DB      15         ;BLM
D82A 00    DB      0          ;EXM
D82B F200 DW      242         ;DSM
D82D 7F00 DW      127         ;DRM
D82F C0    DB      0C0H      ;AL0
D830 00    DB      0          ;AL1
D831 2000 DW      32          ;CKS
D833 0200 DW      2           ;OFF
D835 12    DB      12H       ;16*((#CPM SECTORS/PHYSICAL SECTOR) -1) +
                                ;LOG2(#BYTES PER SECTOR/128) + 1 +
                                ;8 IF DOUBLE SIDED.

```

```

*****
*
* THE FOLLOWING DPB DEFINES A DISKETTE AS 512 BYTE SECTORS,
* DOUBLE DENSITY, AND SINGLE SIDED.
*
*****

```

```

D836 3C00 DPB512S DW      60      ;CP/M SECTORS/TRACK
D838 04    DB      4          ;BSH
D839 0F    DB      15         ;BLM
D83A 00    DB      0          ;EXM
D83B 1801 DW      280         ;DSM
D83D 7F00 DW      127         ;DRM
D83F C0    DB      0C0H      ;AL0
D840 00    DB      0          ;AL1
D841 2000 DW      32          ;CKS
D843 0200 DW      2           ;OFF
D845 33    DB      33H       ;16*((#CPM SECTORS/PHYSICAL SECTOR) -1) +
                                ;LOG2(#BYTES PER SECTOR/128) + 1 +
                                ;8 IF DOUBLE SIDED.

```

```

*****
*
* THE FOLLOWING DPB DEFINES A DISKETTE AS 1024 BYTE SECTORS,
* DOUBLE DENSITY, AND SINGLE SIDED.
*
*****

```

```

D846 4000 DP1024S DW      64      ;CP/M SECTORS/TRACK
D848 04    DB      4          ;BSH
D849 0F    DB      15         ;BLM
D84A 00    DB      0          ;EXM
D84B 2B01 DW      299         ;DSM
D84D 7F00 DW      127         ;DRM

```



```

D84F C0      DB      0C0H      ;AL0
D850 00      DB      0         ;AL1
D851 2000    DW      32        ;CKS
D853 0200    DW      2         ;OFF
D855 74      DB      74H       ;16*((#CPM SECTORS/PHYSICAL SECTOR) -1) +
                                ;LOG2(#BYTES PER SECTOR/128) + 1 +
                                ;8 IF DOUBLE SIDED.

```

```

*****
*
* THE FOLLOWING DPB DEFINES A DISKETTE FOR 128 BYTE SECTORS,
* SINGLE DENSITY, AND DOUBLE SIDED.
*
*****

```

```

D856 3400    DPB128D DW      52      ;CP/M SECTORS/TRACK
D858 04      DB      4           ;BSH
D859 0F      DB      15          ;BLM
D85A 01      DB      1           ;EXM
D85B F200    DW      242         ;DSM
D85D 7F00    DW      127         ;DRM
D85F C0      DB      0C0H       ;AL0
D860 00      DB      0           ;AL1
D861 2000    DW      32          ;CKS
D863 0200    DW      2           ;OFF
D865 09      DB      9H

```

```

*****
*
* THE FOLLOWING DPB DEFINES A DISKETTE AS 256 BYTE SECTORS,
* DOUBLE DENSITY, AND DOUBLE SIDED.
*
*****

```

```

D866 6800    DPB256D DW      104     ;CP/M SECTORS/TRACK
D868 04      DB      4             ;BSH
D869 0F      DB      15            ;BLM
D86A 00      DB      0             ;EXM
D86B E601    DW      486            ;DSM
D86D FF00    DW      255            ;DRM
D86F F0      DB      0F0H          ;AL0
D870 00      DB      0             ;AL1
D871 4000    DW      64             ;CKS
D873 0200    DW      2             ;OFF
D875 1A      DB      1AH

```

```

*****
*
* THE FOLLOWING DPB DEFINES A DISKETTE AS 512 BYTE SECTORS,
* DOUBLE DENSITY, AND DOUBLE SIDED.
*
*****

```

```

D876 7800    DPB512D DW      120     ;CP/M SECTORS/TRACK
D878 04      DB      4             ;BSH
D879 0F      DB      15            ;BLM

```

D87A 00	DB	0	;EXM
D87B 3102	DW	561	;DSM
D87D FF00	DW	255	;DRM
D87F F0	DB	0F0H	;AL0
D880 00	DB	0	;AL1
D881 4000	DW	64	;CKS
D883 0200	DW	2	;OFF
D885 3B	DB	3BH	

```

*****
*
* THE FOLLOWING DPB DEFINES A DISKETTE AS 1024 BYTE SECTORS,
* DOUBLE DENSITY, AND DOUBLE SIDED.
*
*****

```

D886 8000	DP1024D	DW	128	;CP/M SECTORS/TRACK
D888 04	DB	4	;BSH	
D889 0F	DB	15	;BLM	
D88A 00	DB	0	;EXM	
D88B 5702	DW	599	;DSM	
D88D FF00	DW	255	;DRM	
D88F F0	DB	0F0H	;AL0	
D890 00	DB	0	;AL1	
D891 4000	DW	64	;CKS	
D893 0200	DW	2	;OFF	
D895 7C	DB	7CH		

```

*****
*
* CP/M DISK PARAMETER HEADERS, UNINITIALIZED.
*
*****

```

D896 0000	DPZERO	DW	0	;ADDRESS OF TRANSLATION TABLE (FILLED ; IN BY SETDRV)
D898 0000000000	DW	0,0,0	;USED BY BDOS	
D89E 1BDF	DW	DIRBUF	;ADDRESS OF DIRECTORY BUFFER	
D8A0 0000	DW	0	;ADDRESS OF DPB (FILLED IN BY SETDRV)	
D8A2 1BDE	DW	CSV0	;DIRECTORY CHECK VECTOR	
D8A4 EFDC	DW	ALV0	;ALLOCATION VECTOR	
D8A6 0000	DPONE	DW	0	
D8A8 0000000000	DW	0,0,0		
D8AE 1BDF	DW	DIRBUF		
D8B0 0000	DW	0		
D8B2 5BDE	DW	CSV1		
D8B4 3ADD	DW	ALV1		
D8B6 0000	DPTWO	DW	0	
D8B8 0000000000	DW	0,0,0		
D8BE 1BDF	DW	DIRBUF		
D8C0 0000	DW	0		
D8C2 9BDE	DW	CSV2		
D8C4 85DD	DW	ALV2		

```

D8C6 0000 DPTHRE DW 0
D8C8 00000000 DW 0,0,0
D8CE 1BDF DW DIRBUF
D8D0 0000 DW 0
D8D2 DBDE DW CSV3
D8D4 D0DD DW ALV3

```

```

*****
*
* ROUTINE FOR OKIDATA PRINTER
*
*****

```

```

D8D6 DB02 COPTR IN 2 ;INPUT FROM PORT 2
D8D8 E608 ANI 8 ;WAIT UNTIL OK TO SEND
D8DA CAD6D8 JZ COPTR
D8DD DB05 COPTR1 IN 5 ;BUFFER FULL?
D8DF E601 ANI 1
D8E1 CADDD8 JZ COPTR1 ;WAIT UNTIL PRINTER READY
D8E4 79 MOV A,C ;OUTPUT THE CHARACTER
D8E5 D300 OUT 0
D8E7 C9 RET

```

```

*****
*
* CBIOS RAM LOCATIONS THAT DON'T NEED INITIALIZATION.
*
*****

```

```

D8E8 00 CPMSEC DB 0 ;CP/M SECTOR #
D8E9 00 CPMDRV DB 0 ;CP/M DRIVE #
D8EA 00 CPMTRK DB 0 ;CP/M TRACK #
D8EB 00 TRUESEC DB 0 ;DISK JOCKEY SECTOR THAT CONTAINS CP/M SECTOR
D8EC 00 BUFDRV DB 0 ;DRIVE THAT BUFFER BELONGS TO
D8ED 00 BUFTRK DB 0 ;TRACK THAT BUFFER BELONGS TO
D8EE 00 BUFSEC DB 0 ;SECTOR THAT BUFFER BELONGS TO
D8EF BUFFER DS 1024 ;MAXIMUM SIZE BUFFER FOR 1K SECTORS

```

```

DCEF ALV0 DS 75 ;ALLOCATION VECTOR FOR DRIVE A
DD3A ALV1 DS 75 ;ALLOCATION VECTOR FOR DRIVE B
DD85 ALV2 DS 75 ;ALLOCATION VECTOR FOR DRIVE C
DDD0 ALV3 DS 75 ;ALLOCATION VECTOR FOR DRIVE D
DE1B CSV0 DS 64 ;DIRECTORY CHECK VECTOR FOR DRIVE A
DE5B CSV1 DS 64 ;DIRECTORY CHECK VECTOR FOR DRIVE B
DE9B CSV2 DS 64 ;DIRECTORY CHECK VECTOR FOR DRIVE C
DEDB CSV3 DS 64 ;DIRECTORY CHECK VECTOR FOR DRIVE D
DF1B DIRBUF DS 128 ;DIRECTORY BUFFER

```

```

DF9B END

```

TERM DRIVER

0006 AACK	000D ACR	0003 AETX	000A ALF	DCEF ALV0
DD3A ALV1	DD85 ALV2	DDD0 ALV3	D3FA AUTOFLG	C500 BDOS
9000 BIAS	D300 BIOS	D8EC BUFDRV	0080 BUFF	D8EF BUFFER
D8EE BUFSEC	D8ED BUFTRK	D5D5 BUFWRN	D3A0 CBOOT	BD00 CCP
0004 CDISK	D715 CICRT	D715 CIPTR	D692 CITBLE	E403 CITYTY
D700 CIUCL	D715 CIUR1	D715 CIUR2	D3F2 CLDBOT	0019 CLEAR
D3FB CMNDBEG	D3FB CMNDEND	D6D2 COCRT	D6D6 COLPT	D64C CONIN
D652 CONIN1	D661 CONOUT	D640 CONST	D6D6 COPTP	D8D6 COPTR
D8DD COPTR1	D69A COTBLE	E406 COTTY	D6E1 COUL1	D6FF COUNT
D6D6 COUPL	D6D6 COUP2	D30C COUT	D5B5 CPMDMA	D8E9 CPMDRV
0016 CPMREV	D8E8 CPMSEC	D8EA CPMTRK	D729 CSCRT	D729 CSPTR
D646 CSREADR	D6C2 CSRTBLE	D6BA CSTBLE	D721 CSTTY	D70C CSUC1
D729 CSUR1	D729 CSUR2	DE1B CSV0	DE5B CSV1	DE9B CSV2
DEDB CSV3	D3F9 CWFLG	0008 DBLSID	DF1B DIRBUF	D583 DIVDONE
D57A DIVLOOP	E403 DJCIN	E406 DJCOUT	E42D DJDEN	E412 DJDMA
D333 DJDRV	E42A DJERR	E409 DJHOME	E400 DJRAM	E415 DJREAD
E40F DJSEC	E41B DJSEL	E430 DJSIDE	E427 DJSTAT	E40C DJTRK
E421 DJTSTAT	E418 DJWRITE	D886 DP1024D	D846 DP1024S	D856 DPB128D
D816 DPB128S	D866 DPB256D	D826 DPB256S	D876 DPB512D	D336 DPB512S
D8A6 DPONE	D8C6 DPTHRE	D8B6 DPTWO	D896 DPZERO	D590 DTSLOP
0005 ENTRY	D620 FILL	D5D4 FLUSH	D541 GETDPB	D3B3 GOCPM
D490 HOME	00C0 INTIOBY	D5C2 INTO	0003 IOBYTE	D681 LIST
D684 LIST1	D63C LISTST	D732 LSLPT	D6CA LSTBLE	D6A2 LTBLE
0004 MAXDISK	D393 MESSAGE	D59F MOVE	D635 MOVER	D637 MOVLOP
E800 MSDV	0038 MSIZE	D45E NEWDMA	D43F NEWSEC	D456 NOWRAP
E000 ORIGIN	D5BD OUTOF	D67C PNCH1	D5DB PREP	D336 PROMPT
D6AA PTBLE	D676 PUNCH	D6F6 PWAIT	D5B8 RDWR	D66C READER
D569 READ	D66F READERA	D672 READR1	D737 READY	D56D REDWRT
000A RETRIES	D5E4 RETRYLP	D612 RETRYOP	001E REVNUM	D6B2 RTBLE
D5A4 SECPSEC	D56E SECSIZ	D497 SECTAN	D656 SELDEV	D48A SETDMA
D4C6 SETDRV	D524 SETDRV1	D485 SETSEC	D492 SETTRK	D4A5 SIDEA
D517 SIDEOK	D4A8 SIDEONE	D4AE SIDETWO	D724 STAT	D73A TINIT
0100 TPA	D8EB TRUESEC	D43E WARML0D	D472 WARMRD	D303 WBOOTE
D3FC WBOOT	0000 WBOT	D400 WFLG	D562 WRITE	D5CC WRITTYP
D475 WRMREAD	D7D5 XLT124	D748 XLT128	D763 XLT256	D793 XLT512
D55A XLTS	D53D ZRET			